

# Penny & Giles – Product Support

Document Number : PS1182  
Revision / Date : 5 / August 15, 2011  
Document Title : Setting the OQAR/PQAR Time and Date.  
Equipment Affected : OQAR & PQAR  
Part Numbers : D52000 (All models)  
Classification : Information

## Introduction.

The TIME and DATE setting functions are accessed from the 01 OPERATOR menu:

The OQAR/PQAR displays the time as HH:MM:SS, where HH is the hours (numbers in the range 0-23), MM is the minutes (numbers in the range 0-59) and SS is the seconds (numbers in the range 0-59).

The OQAR/PQAR displays the date DD/MM/YY, where DD is the day (numbers in the range 01-31), MM is the month (numbers in the range 01-12) and YY is the year (numbers in the range 00-99).

## Notes.

1. To confirm a selection press the ENTER key, but to abandon the selection press the EXIT key.
2. Repeatedly pressing the EXIT key will back up the menu system until the default display of TIME and DATE is displayed. Press the EXIT key again to then display the 01 OPERATOR menu.

## Procedure.

In order to set the OQAR/PQAR Time & Date variables, follow this procedure:

1. Press the EXIT key to display the 01 OPERATOR menu (you may have to press this key more than once to display this menu).
2. Press the ENTER key to select the 01 OPERATOR menu, the first menu item ACTIVITY will be displayed.
3. Press the PLUS and MINUS keys to gain access to the SET\_TIME menu option (please refer to the OQAR/PQAR menu summary table for the menu sequences available).
4. Press the ENTER key to access the SET\_TIME function. The first digit at the left side of the upper display will be flashing.
5. Press the PLUS and MINUS keys to change the first part of the hour number. When you have selected the correct number press the ENTER key to confirm your selection and to move onto the next number.
6. Repeat step 5 for each number digit in the time sequence. Please note the OQAR/PQAR requirement for 2 character sequences, with leading zero's where necessary.
7. When the last time number digit has been entered use the PLUS and MINUS keys to select the SET\_DATE menu option, then repeat steps 4, 5 & 6 for the date number digits.

# Penny & Giles – Product Support

8. To exit the SET\_TIME or SET\_DATE options press the EXIT key. Press the EXIT key to display the 01 OPERATOR menu (you may have to press this key more than once to display this menu).

**Additional References:** PS1172 - OQAR Time and Date Formats.DOC.

---

## Product Support Contact Information

Telephone : +44 (0) 1202 409409  
Fax : +44 (0) 1202 484846  
Email : [support@pennyandgiles.com](mailto:support@pennyandgiles.com)